

# SUBLIMITY FIRE DISTRICT

## Operational Guide

**SUBJECT:** Large Volume Flows

O.G. NUMBER:

**PURPOSE:** To describe the Large Volume Flows

Original Date: 5/10/98

Revision Date:

A 4 1/2" male x 2 1/2" female adapter is located on the hydrant adapter stack on E 50, 51 and 52.

During fires where a large quantity of water is needed and no streamer connection is on the hydrant, this adapter will be used on a 2 1/2" hydrant outlet. Any other 2 1/2" outlets will be gated for future use.

During fires where a large quantity of water is needed and a streamer is on the hydrant, the large diameter hose will be used on the hydrant.

Apparatus used for water supply at large fires will be located at the hydrant whenever possible.